


# DIAL TEST INDICATOR UNIVERSAL HOLDER



6297-1



- Set the indicators at the desired attitude to the workpiece

Code

6297-1

