


## Spare parts for dial height gage 1351 series



| Part NO. | Code                 | Description                                              |
|----------|----------------------|----------------------------------------------------------|
| 1        | SP-POINTER-1351      | Pointer                                                  |
| 2        | BPN-1351-300         | Dial plate Inside (1351-300)                             |
|          | BPN-1351-450         | Dial plate Inside (1351-450)                             |
|          | BPN-1351-600         | Dial plate Inside (1351-600)                             |
|          | BPN-1351-12          | Dial plate Inside (1351-12)                              |
|          | BPN-1351-18          | Dial plate Inside (1351-18)                              |
|          | BPN-1351-24          | Dial plate Inside (1351-24)                              |
| 3        | BPW-1351             | Dial Plate Outside                                       |
|          | BPW-1351-12          | Dial Plate Outside 12"/24"                               |
| 4        | SP-GLASS-1351        | Glass                                                    |
| 5        | SP-BEZEL-1351        | Bezel                                                    |
| 6        | SP-1351-IN-LAB       | Panel for 1351 (inch)                                    |
|          | SP-1351-LAB          | Panel for 1351 (mm)                                      |
| 7        | SP-HANDLE-1151       | Handle wheel                                             |
| 8        | SP-COUNTER-1351-1    | Count Appliance for 1351-300 (set)                       |
|          | SP-COUNTER-1351-2    | Count Appliance for 1351-450/-600 (set)                  |
|          | SP-COUNTER-1351-12   | Count Appliance for 1351-12 (set)                        |
|          | SP-COUNTER-1351-24   | Count Appliance for 1351-18/-24 (set)                    |
| 9        | SP-CLAMP-1151-1      | Clamp for 1151 /1351 serial                              |
| 10       | SP-CONNECTION-1351-1 | Connection for 1351-300 (the number of teeth is 16)      |
|          | SP-CONNECTION-1351-2 | Connection for 1351-450/-600 (the number of teeth is 16) |
| 11       | SP-LOCKING-1351      | Locking for 1351                                         |