

Spare parts for dial indicator 2324 series



| Part NO. | Code                 | Description       |
|----------|----------------------|-------------------|
| 1        | SP-DUST CAP-2324     | Dust cap          |
| 2        | SP-DIAL-FAGGING-2324 | Protecting jacket |
| 3        | SP-POINT-RK-2324     | Contact point     |
| 4        | SP-MAIN GEAR-2324    | Main gear         |
| 5        | SP-DIAL-GLASS-2324   | Dial glass        |