


BORE GAGE FOR BARRIER INSIDE BORE

ATTENTION: NOT SUITABLE
FOR 0.001MM DIAL INDICATORS

MEASURE DIAMETER OF
BORES WITH BARRIER INSIDE



- Measure diameter of bores with barrier inside
- Optional accessory:
 - 0.01mm graduation dial indicators
 - Setting ring (code **6312**)



application



(mm)

Code	Range ØD	Diameter of barrier Ød	Travel of measuring tip	Accuracy (without dial indicator)	Measuring force
2348-210*	40-210mm	<D-14 (less than 50mm)*	1.6	0.018	2N

* For example:

When measuring size ØD is 40mm, D-14=26mm, so the diameter of barrier should be less than 26mm.
When measuring size ØD is 70mm, D-14=56mm, however it should be less than 50mm, so the diameter of barrier should be less than 50mm.

dial indicator
is optional



2348-210