


Spare parts for thickness gage 2365



Part NO.	Code	Description
1	SP-DIAL-2365-10	Dial for 2365-10/-10B(include part NO. 3, 4)
2	SP-TIP-2365	Tips for 2365-10 and 2365-20 (Supply in pairs)
3	SP-LIFT-LEVER-2365-10	Lift for 2365-10/-10B
	SP-LIFT-LEVER-2365-20	Lift for 2365-20/-20B
4	SP-LIFT-LEVER SCREW	Lifting level screw