


Spare parts for centering indicator 2385 series



Part NO.	Code	Description
1	SP-RESTRAINING -ARM	Restraining arm
2	SP-SPANNER-2385	Spanner
3	SP-DIAL-INDICATOR-2385-3	Dial indicator for 2385-3
4	SP-DIAL-SCREW-2385	Fixed screw for dial indicator
5	SP-LOCK-SCREW-2385	Lock screw
6	SP-EXTERNAL-2385-40	40mm external feeler
	SP-EXTERNAL-2385-90	90mm external feeler
	SP-EXTERNAL-2385-140	140mm external feeler
7	SP-INTERNAL-2385-40	40mm internal feeler
	SP-INTERNAL-2385-90	90mm internal feeler
	SP-INTERNAL-2385-140	140mm internal feeler
8	SP-SPRING-FEELER	Spring loaded feeler
9	SP-BLACK-SUPPORT-2385	Black support for 2385
10	SP-DIAL-GLASS-2385	Glass
11	SP-DIAL-2385-3	Dial plate for 2385-3
12	SP-GEAR-2385	Gear for 2385
13	SP-BEZEL-2385	Bezel
14	SP-PLASTIC-CLIP-2385	Plastic clip for 2385-3
15	SP-CENTER-SHAFT-2385	Center shaft for 2385-3
16	SP-SUPPORT-SCREW-2385	Screw
17	SP-MARK-2385	Tolerance mark
18	SP-WASHER-2385	Washer
19	SP-NEEDLES-1-2385	Big needle
20	SP-NEEDLES-2-2385	Small needle
21	SP-PINWASHER-2385	Pin and washer for 2385-3