


Spare parts for thickness gage 2862



Part NO.	Code	Description
1	SP-BEZEL-2862	Bezel for 2862 series
2	SP-POINTER-2862	Pointer for 2862 series
3	SP-SPIRAL-SPRING-2862-101	Spiral spring for 2862-101 (include the gear)