


Spare parts for feeler gage 4602 series



Part NO.	Code	Description
1	SP-IS-4602LM	Screw nut
2	SP-4602-0D02	0.02mm feeler gage
	SP-4602-0D03	0.03mm feeler gage
	SP-4602-0D04	0.04mm feeler gage
	SP-4602-0D10	0.10mm feeler gage
	SP-4602-0D15	0.15mm feeler gage
	SP-4602-0D20	0.20mm feeler gage
	SP-4602-0D23	0.23mm feeler gage
	SP-4602-0D25	0.25mm feeler gage
	SP-4602-0D28	0.28mm feeler gage
	SP-4602-0D30	0.30mm feeler gage
	SP-4602-0D33	0.33mm feeler gage
	SP-4602-0D35	0.35mm feeler gage
	SP-4602-0D38	0.38mm feeler gage
	SP-4602-0D45	0.45mm feeler gage
	SP-4602-0D50	0.50mm feeler gage
	SP-4602-0D55	0.55mm feeler gage
	SP-4602-0D60	0.60mm feeler gage
	SP-4602-0D63	0.63mm feeler gage
	SP-4602-0D65	0.65mm feeler gage
	SP-4602-0D70	0.70mm feeler gage
	SP-4602-0D75	0.75mm feeler gage
	SP-4602-0D80	0.80mm feeler gage
	SP-4602-0D90	0.90mm feeler gage
	SP-4602-1D00	1.00mm feeler gage
	SP-4602-17-02	0.02mm feeler gage
	SP-4602-17-03	0.03mm feeler gage
	SP-4602-17-04	0.04mm feeler gage
	SP-4602-17-05	0.05mm feeler gage
	SP-4602-17-07	0.07mm feeler gage