


Spare parts for magnetic stand 6200, 6201 and 6202 series



Part NO.	Code	Description
1	SP-STAND-STEM-12	Stand bar for 6200-60 and 6201-60
	SP-BAR-6202-80	Stand bar for 6202-80
	SP-BAR-6202-100	Stand bar for 6202-100
2	SP-VICE-ROD-6200	Vice bar for 6200-60(no fine adjustment device)
	SP-VICE-BAR-6201-60	Vice bar for 6201-60
	SP-VICE-BAR-6202-80	Vice bar for 6202-80
	SP-VICE-BAR-6202-100	Vice bar for 6202-100
3	SP-MAGNETIC-BASE-6205	Magnetic Base for 6200-60 and 6201-60
	SP-MAGNETIC-BASE-6202-80	Magnetic Base for 6202-80
	SP-MAGNETIC-BASE-6202-100	Magnetic Base for 6202-100
4	SP-STAND-KNOB-6200	Knob for 6200, 6201 and 6202 series
5	SP-CLAMPING-DEVICE-6201	Clamp device(included the shim)
6	SP-BACK-HOLDER-1	Lug back holder for 6200, 6201 and 6202 series
7	SP-CLAMPING-HOLDER-6201	clamp holder for 6200-60 and 6201-60
	SP-CLAMPING-HOLDER-6202	clamp holder for 6202-80 and 6202-100
8	SP-STAND-SLEEVE	Sleeve (8mm)
9	SP-STAND-KNOB-6200-1	Tightening knob for vice bar of 6200-60 and 6201-60(not include part No.6, NO.8)
	SP-HOLDER-6202-1	Tightening knob for vice bar of 6202-80 and 6202-100(not include part No.6, NO.8)
10	SP-STAND-KNOB-6200-2	Tightening knob for stand bar of 6200-60 and 6201-60
	SP-STAND-KNOB-6202-1	Tightening knob for stand bar of 6202-80
	SP-STAND-KNOB-6202-3	Tightening knob for stand bar of 6202-100
11	SP-FINE-ADJ-SCREW-6201	Fine adjustment screw for 6201 and 6202
12	SP-STAND-SPANNER	Spanner for 6200/6201