



www.insize.com



8003 WEIGHING SCALES INSTRUCTION MANUAL

PLEASE SCAN QR CODE TO
WATCH THE OPERATION
VIDEO OF PRODUCTS.



1. Description

- <1> capacity /division.
3000g/0.1g 6000g/0.5g 10000g/1g
- <2> auto return to zero function.
- <3> automatic shutdown function.
- <4> low power consumption and low power display "LO".
- <5> overload shows "O-Ld".
- <6> unit changeable between g, oz, lb, and tl.
- <7> battery charging.

2. Button

- <1> "TARE" key, turn on/off, tare and zero.
- <2> "UNIT" key, the conversion between units.

3. Operation steps

Step 1: put the scale on the table to keep the level.
 Step 2: press the "TARE" key, and the "0" will be displayed after 2 seconds.
 Step 3: place the item at the middle of the pan and the display will show the weight.

■ **TARE:** When using containers, containers can be placed on scales. The display will show the weight of the containers. Press the "TARE" button, when the display show as "0", re-load the items for weighing, you can get the net weight of the items.

■ **CHARGE:** The standard small USB socket data line is used to connect the charging port for 6 hours continuously, and the battery can be used for 3 months after the battery is saturated.

■ **SHUTDOWN:** Display window display "0" state, according to "TARE" key can turn off, in 60 seconds without any operation, the scale will automatically turn off.

■ **UNIT CHANGEABLE:** Press the "UNIT" key, you can choose the conversion between "g", "oz", "lb", "tl" units.

■ **OVERWEIGHT:** If the items are placed beyond the maximum weighing of the scale, the display of the scale will show "O-Ld".

4. Attention

- <1> When the electronic scale is used, it should be placed horizontally and can not be used in a vibrating environment.
- <2> Strictly prohibit overloading, and it is strictly prohibited to use heavy weight to impact electronic scales.
- <3> No rain, water washing, no water in the machine, do not drop the electronic scale from the height.
- <4> LCD displays "LO" weak electricity prompt, indicate the battery voltage is too low, please replace the battery immediately.
- <5> Please use it in the range of 0°C ~40°C to avoid the excessive temperature change.
- <6> The electronic scales are precision instruments, when to put something on the tray, do not press the tray.
- <7> When the electronic scale is in the state of wages, do not move the scale, so as not to affect the accuracy of weighing.
- <8> When the surface of the electronic scale is stained, wipe with wet cloth, please do not use any chemical.
- <9> The charge time of the battery must not exceed 8 hours.
- <10> It is not allowed for the user to disassemble repair electronic scales, such as a fault, please contact the local dealer.

5. ALARM

Warning signal	Possible reason	Remedy
"O-Ld" appears when it's being used	Overload	Taking out some items will be able to resume weighing.
Display appears "LO"	Low battery voltage	Replace with a new battery